



Measuring guide for a sliding screen














SLIDING WING ELEMENTS FOR SYSTEM A AND B

1	¥	x2	2	x2
3		x4	4	x4
5		x2	6	x1
7		x1	8	x1
9		x1		




ASSEMBLYA						
		OP1 x 2 pcs		1	OP1 x 2 pcs	
1		OP2 x 2 pcs	2		DR2	
		OP3 x 1 pce) RS	
) PRÍ			OP1 x 4 pcs	
3		DR2	4) PR2	
		OP3 x 1 pce) R S	
		DRÍ			OP1 x 2 pcs	
5	1 1	OP2 x 4 pcs	6		OP2 x 2 pcs	
		OP3 x 2 pcs			OP3 x 2 pcs	
	0	OP1 x 8 pcs			OP1 x 4 pcs	
7) R2	8		OP2 x 12 pcs	
) RS		T.	OP3 x 8 pcs	
	13	OP1 x 8 - 14	pcs			
9		OP2 x 4 - 8 pcs				
		OP3 x 2 - 4 p	ocs			

ASSEMBLY A






Necessary tools for the correct installation of a mosquito net





Montage A


Applies to sliding mosquito nets ordered without pre-drilled mounting points.






Montage B

Applies to sliding mosquito nets ordered without pre-drilled mounting holes.







Assembling the frame from the guides.






































<u> 100mm</u>		
• •		
• •	00	00










Mounting in the recess



Attention, please:

Once the slides have been prepared, try them on at the intended installation location and mark the limit points at which they are to be located to facilitate the transfer of the required dimensions.




Mounting in the recess

Attention, please:


The diagram shows an example of mounting a sliding mosquito net guide in a door or window recess. When installing, pay attention to the material of the recess in which the guides are to be fixed. Use only connectors dedicated to the material to which the mosquito net will be mounted to.







Outdoor mounting on a recess or on a door or window frame.




Once the slides have been prepared, try them on at the intended installation location and mark the limit points at which they are to be located, making it easier to move the required dimensions.

Outdoor mounting on a recess or on a door or window frame.

Attention, please:


The diagram shows an example of mounting a sliding mosquito net guide on the outside of a door or window recess. When installing, pay attention to the material of the recess to which the guides will be attached. Use only connectors dedicated to the material to which the mosquito net will be mounted.






Inserting brush gaskets into the wing profiles of a mosquito net

A B OP1 OP2 OP3












Fixing rollers and slides in the wing of a mosquito net.








Fitting a mesh in the wing of a mosquito net.


A B OP1 OP2 OP3






Inserting the mosquito net wing into the guides and adjusting the level.









Attention, please :

If a sliding mosquito net has more than one wing, we insert the wings into the guides and adjust them in the same way as the first wing. When assembling, make sure that you do not confuse the running rails on which the individual wings of the mosquito net are mounted.

